



Installation Instructions

PART NUMBERS: 75908, 87665, 44750

WARNING

To prevent **SERIOUS INJURY, DEATH** or **PROPERTY DAMAGE**:

- **ALWAYS** read, understand and follow warnings and instructions for your hitch **BEFORE** installation. Keep for future reference.
- **DO NOT** cut, weld or modify this receiver.
- **CHECK** all fasteners are tight and your hitch is securely mounted to your vehicle periodically.
- **ALWAYS** read, understand and follow all warnings and instructions for your vehicle and for other accessories you will use with your hitch **BEFORE** use.
- **LOAD** the trailer heavier in front.
- **DO NOT** exceed lower of towing vehicle manufacturer’s rating or:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	5000 lb. (2270 kg)	500 lb. (227 kg)
Weight Distributing	NA	NA

- **ALWAYS** wear your seatbelt.
- **SLOW DOWN** when towing, **NEVER** exceed any posted speed limit.
- If **EXCESS SWAY** occurs, take your foot off the gas pedal and hold the steering wheel as steady as possible. **DO NOT** apply your brakes and **DO NOT** speed up.

LIMITED LIFETIME WARRANTY

1. **Limited Lifetime Warranty (“Warranty”).** Cequent Performance Products, Inc. (“We”, “Us” or “Our”) warrants to the original consumer purchaser only (“You” or “Your”) that the product will be free from material defects in both material and workmanship, ordinary wear and tear excepted. The Warranty is valid only if (a) the products are returned to Us for inspection and testing; (b) Our inspection discloses to Our satisfaction that any alleged nonconformance are material and have not been caused by misuse, neglect, wear and tear, improper installation, unsuitable storage, improper repair, alteration, or accident; and (c) the products were installed, maintained and used in accordance with Our instructions. **THE WARRANTY IS MADE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED (OTHER THAN THE WARRANTY OF TITLE AS PROVIDED BY THE UNIFORM COMMERCIAL CODE IN EFFECT IN MICHIGAN), INCLUDING WITHOUT LIMITATION, ANY WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SAID WARRANTIES BEING EXPRESSLY DISCLAIMED.**
2. **Obligations of Purchaser.** To make a Warranty claim, contact Us at our principal address of 47912 Halyard Drive, Suite 100, Plymouth, MI 48170, 1-800-632-3290, identify the product by model number, and follow the claim instructions that will be provided. Any returned product that is replaced by Us becomes our property. You may be responsible for return shipping costs. Please retain your purchase receipt to verify date of purchase and that You are the original consumer purchaser. The product and the purchase receipt must be provided to Us in order to process Your Warranty claim.
3. **Exclusive Remedy.** Product replacement is Your sole and exclusive remedy under this Warranty. We shall not be liable for service or labor charges incurred in removing or replacing a product. **IN NO EVENT WILL WE BE RESPONSIBLE FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES.**
4. **Assumption of Risk.** You acknowledge and agree that any use of the product for any purpose other than the specified use(s) stated in the product instructions is at Your own risk.
5. **Governing Law.** This Warranty gives You specific legal rights, and You also may have other rights which vary from state to state. This Warranty is governed by the laws of the State of Michigan, without regard to rules pertaining to conflicts of law. The state courts located in Oakland County, Michigan shall have exclusive jurisdiction for any disputes relating to this Warranty.



Installation Instructions

PART NUMBERS: 75908, 87665, 44750

Applications:


Years	Make	Models
-------	------	--------

2016-Current*	Kia	Sorento
---------------	-----	---------

*Visit our website for the most up to date information regarding application years and trim levels.


Installation Time: **40 Min.**

The time listed above is the average time for professional installers. If you do not feel comfortable performing this installation on your own or are in need of assistance, please contact a professional installer.




Representative Vehicle Photo

Equipment Required:



DO NOT EXCEED LOWER OF TOWING VEHICLE MANUFACTURER'S RATING OR:

Hitch Type	Max Gross Trailer Weight	Max Tongue Weight
Weight Carrying	5000 lb. (2270 kg)	500 lb. (227 kg)
Weight Distributing	NA	NA



Hitch Illustration

Always wear SAFETY GLASSES when installing hitch

Installation Instructions

PART NUMBERS: 75908, 87665, 44750

Fastener Kit: 75908F



Teeth side against hitch or frame

Figure 2




Figure 1

Note: sort hardware prior to hitch installation to confirm conical washer are kept with coordinated bolts.

①	Qty. (2)	Hex bolt ½-13 x 4.50 GR5	
②	Qty. (5)	Conical washer ½"	
③	Qty. (2)	Hex Nut ½ -13	
④	Qty. (1)	Bolt M12X1.75X120 CL8.8	
⑤	Qty. (1)	Flat washer ½" hardened	
⑥	Qty. (1)	Hex nut M12X1.75 CL8	
⑦	Qty. (4)	Bolt M10X1.25X30 CL10.9	
⑧	Qty. (4)	Conical washer 7/16"	

1. Lower and remove spare tire from vehicle. The tire release is located underneath the storage compartment in the back of the vehicle.
 2. Remove the driver side rear plastic cover, located underneath the vehicle, by using a small Phillips head screwdriver to remove fasteners, also remove (5) plastic push pins and (2) nuts.
 3. Lower exhaust by removing the rear and side hangers, support the exhaust to prevent damage. Spraying a lubricant or soapy water on the metal hanger rod and the rubber isolator helps removal. Remove rubber plugs from bottom of frame rail. Both sides
 4. Run the M10 bolts into existing weldnuts in frame rail to remove any debris. Remove bolts.
 5. Raise hitch into position and insert (items 1 & 2) on driver's side, and (item 4 & 5) on passenger's side. Insert bolts through the bracket and frame as shown in Figure 1 for support. Note: The bumper locator pin may interfere with the hitch hardware. If necessary, use an angle grinder to trim the locator pin at the shoulder to allow proper hardware clearance.
 6. Insert M10 bolts (item 8 & 7) through bracket and into the frame as shown in Figure 1 (Hand tighten).
 7. Install remaining conical washers and hex nut onto matching bolts.
 8. **Tighten M10 CL10.9 fasteners with torque wrench to 40 Lb.-Ft. (54 N*M), both 1/2 GR5 fasteners with torque wrench to 75 Lb.-Ft. (102 N*M) and M12 GR 8.8 fasteners with torque wrench to 68 Lb.-Ft. (92 N*M).**
- ⚠ Proper torque is needed to keep the hitch secure to the vehicle when towing.**
9. Raise exhaust back into position.
 10. Reinstall driver side rear plastic cover, removed in Step 2.
 11. Reinstall spare tire and make sure it is seated properly.

Note: check hitch frequently, making sure all fasteners and ball are properly tightened. If hitch is removed, plug all holes in trunk pan or other body panels to prevent entry of water and exhaust fumes. A hitch or ball which has been damaged should be removed and replaced. Observe safety precautions when working beneath a vehicle and wear eye protection. Do not cut access or attachment holes with a torch.


1. Lower and remove spare tire from vehicle. The tire release is located underneath the storage compartment in the back of the vehicle.



2. Remove the driver side rear plastic cover, located underneath the vehicle, by using a small Phillips head screwdriver to remove fasteners, also remove (5) plastic push pins and (2) nuts.



3. Lower exhaust by removing the rear and side hangers, support the exhaust to prevent damage. Spraying a lubricant or soapy water on the metal hanger rod and the rubber isolator helps removal. Remove rubber plugs from bottom of frame rail. Both sides



4. Run the M10 bolts into existing weldnuts in frame rail to remove any debris. Remove bolts.



5. Raise hitch into position and insert (items 1 & 2) on driver's side, and (item 4 & 5) on passenger's side. Insert bolts through the bracket and frame as shown in Figure 1 for support. Note: The bumper locator pin may interfere with the hitch hardware. If necessary, use an angle grinder to trim the locator pin at the shoulder to allow proper hardware clearance.



6. Insert M10 bolts (item 8 & 7) through bracket and into the frame as shown in Figure 1 (Hand tighten).



7. Install remaining conical washers and hex nut onto matching bolts.



8. Tighten M10 CL10.9 fasteners with torque wrench to 40 Lb.-Ft. (54 N*M), both 1/2 GR5 fasteners with torque wrench to 75 Lb.-Ft. (102 N*M) and M12 GR 8.8 fasteners with torque wrench to 68 Lb.-Ft. (92 N*M).



9. Raise exhaust back into position.



10. Reinstall driver side rear plastic cover, removed in Step 2.



11. Reinstall spare tire and make sure it is seated properly.

